

BoilerMate III


**An open vented central heating and mains pressure
hot water supply system incorporating
a thermal store**

TWIN BOARD.

Design, Installation and Servicing Instructions

**PLEASE LEAVE THESE
INSTRUCTIONS ADJACENT TO THE
APPLIANCE.**

**ALL MODELS COMPLY WITH THE WATER
HEATER MANUFACTURERS SPECIFICATION
FOR INTEGRATED THERMAL STORES.**



GLEDHILL BOILERMATE III SPECIFICATION

DESCRIPTION	PAGES 2 - 7
SYSTEM DESIGN	PAGES 8 - 14
INSTALLATION	PAGES 15 - 19
COMMISSIONING	PAGES 20 - 23
FAULT FINDING/DIAGNOSTICS	PAGES 24 - 27
APPENDICES	PAGES 28 - 29
SPARE PARTS LIST	PAGES 30 - 31
SALE & WARRANTY TERMS	BACK PAGE

These instructions should be read in conjunction with the installation and servicing instructions issued by the manufacturer of the heat source e.g. the boiler used. Any water distribution and central heating installation must comply with the relevant recommendations of the Regulations and British Standards listed below:-

Regulations

- Gas Safety Regulations
- Building Regulations
- I.E.E Wiring Regulations
- Bylaws of the Local Water Undertaking

British Standards

BS6798, BS5449, BS5546, BS5440:1, BS5440:2, CP331:3, BS6700, BS5258 and BS7593:1992

A competent person as stated in the Gas Safety Regulations must install the BoilerMate heating system. The manufacturer's notes must not be taken as overriding statutory obligations.

The BoilerMate III is not covered by section G3 of the current Building Regulations and is therefore not notifiable to Building Control.

Although the domestic water supply to the BoilerMate III is at mains pressure, it is not necessary to fit an expansion vessel, pressure or temperature relief valve.

The BoilerMate III is only suitable for use with an open vented primary i.e. central heating system.

The information in this manual is provided to assist generally in the selection of equipment. The responsibility for the selection and specification of the equipment must however remain that of the customer and any designers or consultants concerned with the design and installation.

Please Note: We do not therefore accept any responsibility for matters of design, selection or specification or for the effectiveness of an installation containing one of our products.

All goods are sold subject to our Conditions of Sale, which are set out at the rear of this manual.


In the interest of continuously improving the BoilerMate range, Gledhill Water Storage Ltd reserve the right to modify the product without notice, and in these circumstances this document, which is accurate at the time of printing, should be disregarded.

The Gledhill BoilerMate range is a WBS listed product developed in conjunction with British Gas.

This product is manufactured under a BS EN ISO9002 Quality System audited by BSI.

DESCRIPTION

TYPICAL SCHEMATIC OF BOILERMATE III SYSTEM FIGURE 1.1



INTRODUCTION

The BoilerMate III shown schematically in Figure 1.1, is designed and used to provide improved space heating as well as a mains pressure hot water supply system with any remotely sited boiler. A report by the Cranfield Institute of Technology found that heat storage systems give a potential for energy savings of between 5% and 15%.

The principle of a BoilerMate III is to separate the heat generator e.g. a boiler from heat emitters by a thermal store, which evens out the fluctuating demands for heating and hot water. Thus by storing energy produced when the demand is low and discharging it when the demand is high (i.e. during warm up or when hot water is drawn off), a smaller boiler can be used.

An important feature of this concept is that hot water can be supplied directly from the mains at conventional flow rates without the need for temperature and pressure relief safety valves or expansion vessels. This is achieved by passing the mains water through a plate heat exchanger. The outlet temperature of the domestic hot water is maintained by a printed circuit board, which controls the speed of the pump circulating the primary water from the store through the plate heat exchanger.

Any automatic boiler of up to a maximum of 30kW (about 100,000BTU) can be linked to any suitable model of BoilerMate III (see Table 1.1, page 7) and the deciding factor is the space heating and the hot water requirements of a dwelling.

THERMAL STORE

The copper thermal store contains primary water, which is maintained at a temperature close to the maximum boiler flow temperature in winter.

It is efficiently insulated with 'Rockwool' CFC free insulation and cased in a steel case to minimise standing losses.

DOMESTIC HOT WATER

Cold Water Supply

The BoilerMate III units are designed to be fed directly from the mains water supply as shown schematically in Figure 1.2. They fulfil the requirements of Water Bylaw 91, and therefore do not require a check valve to be fitted to the supply pipe.

The performance of the BoilerMate III is directly related to the adequacy of the cold water supply to the dwelling. This must be capable of providing for those services, which could be required to be supplied simultaneously, and this maximum demand should be calculated using procedures defined in BS6700.

BoilerMate will operate at pressures as low as 1 bar and this must be available when the local demand is at its maximum, but the preferred range is between 2 and 3 bar.

As a general guideline, although a 15mm external service may be sufficient for smaller dwellings with one bathroom, a 22mm service (25mm MDPE) is preferred and should be the minimum for larger dwellings.

If a water meter is fitted in the service pipe, it should have a nominal rating to match the maximum hot and cold water peak demand calculated in accordance with BS 6700. This could be up to 50l/min in some properties.

The unit must be fitted strictly in accordance with the requirements of the Local Water Undertaking who should be consulted prior to the installation. In the event of any difficulty please contact us as the manufacturers.

The equipment used in the system should be suitable for a working pressure of 8 bar and approved by the WBS or other relevant standard. If this is not the case a pressure limiting valve will be required which is suitable for the items of equipment with the lowest maximum working pressure.

We recommend that a lockshield pattern gate valve is fitted on the cold inlet to the appliance. This can be used for isolating/maintenance purposes or in areas of high pressure can be used to control the flow through the appliance to 30 litres/minute.

Safety Fittings

It is not necessary to fit control and safety equipment normally associated with mains pressure hot water storage appliances e.g. temperature and pressure relief valves and expansion vessel.

BoilerMate III is WBS listed and a non-return valve is not required. However if the ancillary equipment fitted in the supply to these appliances require a non-return valve then the valve must be fitted directly after the branch to the drinking water i.e. a kitchen sink as shown schematically in Figure 1.2.

Domestic Hot Water Flow Rates

Provided the pipe sizing and the supply pressure is adequate the hot water flow rate should be up to 35l/min. for all models (see Table 1.1).

The domestic hot water outlet temperature is regulated to approximately 52°C by the electronic control system and is not user adjustable. However different factory settings are available for special applications eg. old peoples homes.

DESCRIPTION

Use in Hard Water Areas

There are two options for the pump speed control. Option 'H' must be used in hard water areas above 200ppm. Option 'S' can be used in soft water areas below 200ppm.

A patented control system within the Option 'H' microprocessor offers a more sophisticated level of pump speed control and will help prevent the formation of scale.

Both options ('H' or 'S') prevent domestic hot water from exceeding 55°C for most of the operational times of the appliance.

It is not necessary to fit any form of scale inhibiting equipment in the domestic cold water supply to the BoilerMate when using option 'H'.

If scale should, become a problem the plate heat exchanger is easily isolated and can be replaced with a service exchange unit.




Figure 1.2 Typical hot and cold water distribution network

DESCRIPTION

ELECTRICAL CONTROLS

Mounted in the front panel are two printed circuit boards: one for pump speed control of Domestic Hot Water, the other for wiring all system components (see diagram on page 18).




Figure 1.4 BoilerMate III Standard Control Package

CONTROLS




Figure 1.3 Standard BoilerMate III Package

PACKAGED CONTROL SYSTEM

Standard Equipment

The standard configuration of the BoilerMate III is shown in Figure 1.3. The two printed circuit boards mounted inside the appliance control the operation of the complete system. The system control PCB also acts as the wiring centre for the components. The connection arrangement of the BoilerMate III is shown in Figure 1.4. It is supplied with the following factory fitted equipment: -

1. Boiler/space heating system pump
2. Domestic hot water primary (plate heat exchanger) pump
3. Automatic heating system bypass valve
4. System control PCB
5. Hot water control PCB
6. 3-Port flow share valve
7. Electro-mechanical clock (Figure 1.5) to control the space heating (in conjunction with room thermostat-if fitted).
8. Plate heat exchanger.
9. DHWS flow switch.
10. DHWS temperature sensor.
11. DHW mixing valve.
12. Y type strainer.

DESCRIPTION

Optional Equipment

- A seven-day digital clock/programmer (Figure 1.5) to control the space heating (in conjunction with a room thermostat if fitted).
- A kit to site the clock/programmers shown in Figure 1.5 remotely.
- A no clock option – to be used with any two channel clock for controlling both the operation of the space heating (in conjunction with a room thermostat if fitted) and the charging of the thermal store.




Figure 1.5 Front Panel Mounted
Clock Options for BoilerMate III

ELECTRIC IMMERSION HEATER

If an electric immersion heater is fitted then it must: -

1. Be set to operate at 75°C
2. Be wired to a separate 13A fused and switchable power supply.
3. Not be wired into any of the terminals on the appliance printed circuit boards.

This can be supplied at the time of order as an extra.

Replacement immersion heaters should be obtained only from Gledhill Water Storage Ltd.

TECHNICAL SPECIFICATION

The principal dimensions of the BoilerMate III model range are shown in Figure 1.6 and the technical specification of the units is given in Table 1.1.

DESCRIPTION


Table 1.1 Technical specification of BoilerMate III

	BM120	BM140	BM180	BM200	BM220
Overall dimensions of store (height x diameter)	1425 x 475	1425 x 500	1445 x 550	1650 x 550	1765 x 550
Minimum cupboard size (width x depth)	700 x 550	715 x 600	770 x 650	770 x 650	770 x 650
Primary store capacity (l)	100	115	145	175	190
Weight (kg)					
• Empty	39	41	46	52	60
• Full	139	156	191	227	250
Pipe connections	<ul style="list-style-type: none">All pipe connections 22mm copper compression fittingsDrain connection : R½"			<ul style="list-style-type: none">All pipe connections 28mm copper compression fittingsDrain: R½"	
Maximum working head - Thermal store	6m – suitable for open system only				
Maximum working pressure - Domestic hot water	8 bar				
Hot water flow rate (l/min)	35	35	35	35	35
Maximum boiler size (kW)	15	20	20	30	30
Pumps	Grundfos UPS 15-50			Grundfos UPS 15-60	
• System	Grundfos UPS 15-50			Grundfos UPS 15-50	
• Plate heat exchanger					
3-Port valve	22mm Danfoss HS3 DB22			28mm Danfoss HS3 DB28	
Typical dwelling types					
•Bedrooms	2 – 3	2 – 3	2 – 4	3 – 4	3 – 5
•Bathrooms	1 or	1	1	2	2
•En-suite shower rooms	1	1	2	2	3

NOTES

- The flow rates are for 35°C average temperature rise and assume normal pressure and adequate flow to the appliance.
- All units are supplied complete with an integral feed and expansion cistern. This is easily removed from any model and repositioned remotely up to maximum of 6m above the base of the store if necessary.
- The feed and expansion cistern will fit in any space greater than 530mm high by 500mm square which includes the necessary allowance for ballvalve servicing.
- Any pattern BoilerMate III can be specified 'ET' for use with dual boilers e.g. gas and solid fuel.
- With integrated thermal storage, it is important to note that hot water and heating loads can be supplied simultaneously.
- All BoilerMate III's meet the appropriate requirements of the WMA Specification for Integrated Thermal Stores.
- For hard water areas use suffix 'H', for soft water areas use suffix 'S' after the model number, e.g. BM120H = BoilerMate III model 120 for hard water area.
- Non standard sizes are available to suit smaller cupboard dimensions.
- 28mm 3 Port valve and primary connections and/or a Grundfos 15/60 system pump can be provided for the 120, 140 and 180 models at additional cost.
- All BoilerMate models can be provided for a 10m working head.

SYSTEM DESIGN



Model	Dimensions (mm)							
	A	B	C	D	E	F	G	H
BM120	1425	1260	150	1145	475	700	550	600
BM140	1425	1260	150	1145	500	715	600	625
BM180	1445	1275	160	1145	550	770	650	675
BM200	1650	1485	160	1355	550	770	650	675
BM220	1765	1600	160	1470	550	770	650	675

Note . BoilerMate III is normally supplied with the components on the right hand (as shown) but can be supplied left hand if required.

A minimum of 225mm should be provided to allow access to the ballvalve for servicing and adjustment in accordance with the model byelaws.

Figure 1.6 Principal dimensions of BoilerMate III
(See also Table 1.1)

METHOD OF BOILER SIZING

The efficiency of this system is such that special design criteria apply when calculating the boiler size. It is only necessary to calculate the heating requirements in accordance with BS 5449 and add the following allowances for hot water, which are approximately half the traditional allowances.

Up to 1 bathroom and 1 shower : 1.5kW
Up to 2 bathrooms and 2 showers : 3.0kW
Up to 3 bathrooms and 3 showers : 4.0kW

The primary pipework connecting the boiler and the thermal store should be sized to achieve a maximum of 10°C rise across the boiler or the maximum temperature rise specified by the boiler manufacturer, whichever is smaller but in any instance it should not be less than 22mm copper tube.

Note: There should be no valves in the pipework connecting the boiler to the BoilerMate III.


SYSTEM TEMPERATURES

The heating circuit operates on the normal primary boiler temperatures i.e. 82°C flow and 71°C return. Therefore any traditional hot water radiators or convectors can be used with this system and no special over-sizing of the heat emitters is necessary.

SYSTEM LAYOUTS

The BoilerMate III is supplied as a factory fitted and pre-wired package consisting of: -

1. Boiler/space heating pump
2. Domestic hot water primary pump
3. Automatic heating bypass valve
4. System control PCB
5. Hot water control PCB
6. 3-Port flow share valve
7. Electro-mechanical clock to control the space heating (in conjunction with room thermostat if fitted).
8. Plate heat exchanger.
9. DHWS flow switch.
10. DHWS temperature sensor.
11. DHW mixing valve.
12. Y type strainer.



Boiler Sited Below BoilerMate III

Any boiler can be used when the flow pipe from the boiler to the BoilerMate III rises continuously. No part of the flow pipe should contain a valve or other device (which can be accidentally closed), as this forms the safety open vent should the boiler thermostat fail.

Figure 2.1 Boiler sited below BoilerMate

Boiler must be fitted with overheat thermostat.

The F & E cistern must be fitted at a height which will provide the minimum head required for the boiler.




Figure 2.2 Arrangement with dipped flow and return

SYSTEM DESIGN




Figure 2.3 Low Head Installation using Baxi-Solo 2 Boiler

Boiler with Dipped Flow & Return Pipes to BoilerMate III

If the flow and return pipes between the boiler and the BoilerMate III are dipped, then the boiler **must be fitted with an over-heat thermostat**. In these circumstances the automatic air vents should be fitted as shown in Figure 2.2.

In situations where the headroom is restricted (e.g. in a flat), the boiler manufacturer's instructions with regard to minimum head must be followed. For example, a 'Baxi Solo 2' boiler may be installed in accordance with Figure 2.3. The feed and expansion cistern may be left attached to the store and the whole BoilerMate III raised on a platform to give the required working head.

Boiler Sited above BoilerMate III

If the boiler is above the BoilerMate III as shown in Figure 2.4, the F&E cistern can be detached from the BoilerMate III and sited at a higher level to give at least the minimum working head required for the boiler. However the height of the water level in the F&E cistern from the base of the store should be no greater than 6m.

In this system configuration a gravity check valve is necessary as shown in Figure 2.4 to prevent gravity circulation between the BoilerMate III and the boiler during dormant periods.




Figure 2.4 Boiler Sited Above the Level of BoilerMate
Boiler must be fitted with an overheat thermostat

GENERAL GUIDANCE NOTES ON SYSTEM DESIGN

Heating System

A schematic layout of the heating system in a typical small dwelling is shown in Figure 2.8.

1. If heating of a bathroom radiator or towel rail is required in summer, then it can be piped as a gravity circuit shown schematically in Figure 2.5. The flow pipe to the radiator can be teed into the safety open vent pipe and the return pipe from the radiator can be connected to the store drain connection and the drain moved to the return pipe.
2. If the boiler is fitted at a higher level than a BoilerMate III then it may be necessary to fit a gravity check valve in the primary circuit to prevent reverse circulation during dormant periods.
3. All units come complete with their own feed and expansion cistern. The water level in this tank should be at least 250mm above the highest point on the system including the radiators.
4. The BoilerMate III is only suitable for an open system. The F & E cistern may be detached from the unit and fitted remotely up to 6m above the base of the BoilerMate III i.e. the maximum static pressure in the store must not exceed 0.6bar.
5. The overflow /warning pipe should be installed in material suitable for heating system feed and expansion cisterns in accordance with BS 5449.




Figure 2.5 Arrangement for Connecting Bathroom Radiator or towel Rail Heated by Gravity Circulation

SYSTEM DESIGN

6. An automatic bypass is fitted on the BoilerMate III to compensate for pressure (i.e. flow rate) changes in the heating circuit e.g. when the thermostatic radiator valves close. The system does not require any other bypass valves.

7. The performance characteristics of the system pumps is given in Figures 2.6 and 2.6a.




Figure 2.6 Performance Characteristics of Grunfos UPS 15-50 Pump




Figure 2.6a Performance Characteristics of Grunfos UPS 15-60 Pump

COUPLING GAS AND SOLID FUEL BOILERS TO BOILERMATE

Existing or new solid fuel open fires with a back boiler or a solid fuel boiler can be connected to the BoilerMate III, however if required please discuss this with our Technical Department.

HOT AND COLD WATER SERVICES

A schematic layout of the hot and cold water services in a typical small dwelling is shown in Figure 2.9.

BoilerMate III will operate at mains pressures as low as 1 bar and as high as 8 bar although the preferred range is 2-3 bar. It is also important to check that all other equipment and components in the hot and cold water system are capable of accepting the mains pressure available to the property. If the mains pressure can rise above the maximum working pressure of any item of equipment or component to be fitted in the system a suitable pressure limiting (reducing) valve will be required.

Taps and Valves

1. Aerated taps are recommended to prevent splashing.

Pipe Sizing

To achieve even distribution of the available supply of hot and cold water, it is important in any mains pressure system that the piping in a dwelling should be sized in accordance with BS6700. This is particularly important in a large property with more than one bathroom. However the following rule of thumb guide lines should be adequate for most typical property types: -

1. A 15mm copper or equivalent external service may be sufficient for a small 1 bathroom dwelling (depending upon the flow rate available), but the minimum size for larger dwellings must be 22mm (25mm MDPE).
2. The internal cold feed from the main incoming stop tap to the BoilerMate should be run in 22mm pipe. The hot draw-off should also be run in 22mm as far as the branch to the bath tap.
3. The final branches to the hand basins and sinks should be in 10mm and to the shower in 15mm.
4. The final branches to taps in existing properties, which are in 15mm, **should be restricted** to balance the flow to each outlet.
5. **We would recommend that best results for a balanced system are achieved by fitting appropriate flow regulators to each hot and cold outlet (see Appendix).**
6. For properties where the inlet pressure is high and the flow rates may exceed 30 L/min at any bath hot tap the installer must fit a lockshield pattern gate valve at the cold inlet to the appliance. This should then be adjusted to restrict the maximum flow rate to 30 L/min.

Showers

1. Any type of shower mixing valve can be used as long as both the hot and cold supplies are mains fed. However, **PRESSURE COMPENSATING** shower mixing valves are proven to give better control when more than one fitting are open simultaneously and are therefore **STRONGLY RECOMMENDED**. Thermostatic versions are preferable.
2. The hot water supply to a shower mixing valve should be fed wherever practical directly from the BoilerMate III or be the first draw-off point on the hot circuit.
3. The cold supply to a shower mixing valve should be fed directly from the rising mains via an independent branch.
4. **Fixed head type showers:** No back-syphonage arrangements are necessary.
5. **Loose or Flexible head type showers:** If a loose head shower with a flexible hose is used over a bath then: -
 - The hose must be fixed so that the head cannot fall closer than 25mm above the top edge of the bath as specified in the Byelaw 16 of the Model Water Supply Byelaws.

Or

 - The shower must incorporate or be fitted with the necessary check valves to provide back-syphonage protection in accordance with the Model Water Byelaws.

Bidets

1. The supply of hot and cold mains water directly to a bidet is permitted provided that it is of the over-rim flushing type and that a type 'A' air gap is incorporated.
2. It must not include either an ascending spray or provision to attach a hand spray.


Plastic Pipework

This appliance is suitable for use with plastic pipework as long as the material is recommended for the purpose by the manufacturer and is installed fully in accordance with their recommendations.

We recommend the use of barrier pipe, which will mean the system can have British Gas service cover in regions offering this service.

SYSTEM DESIGN

Heating Figure 2.8



NOTES



The flow and return from the boiler always run directly to the BoilerMate III and the flow should rise continuously to facilitate venting.

Where this is not possible, refer to pages 9 & 10

The heating circuit is taken from the BoilerMate III, and is piped in the conventional manner.

— return
— flow

Plumbing Figure 2.9



— cold
— hot

INSTALLATION INSTRUCTIONS

Important Notes

1. It is important that the appliance is installed on a level and even floor or if raised above the base should be continuously supported. If the support is timber, it shall be marine ply, type C4 chipboard to B.S. 5669 or other material which will not deteriorate if exposed to moisture. Details of the appliance weight when full is provided in Table 1.1 of technical specification.

1. Installers are advised that the **combined feed and open vent pipe** arrangement **must not** be used in BoilerMate installations.

2. It is recommended that any surface mounted heating and HWS pipework in the BoilerMate III cupboard **must be insulated** to reduce the standing losses and to prevent unnecessarily high cupboard temperatures. More heat is lost from the first metre of pipework than from the store.

Note: It is now a requirement of Part L of the Building Regulations that all hot water pipework within 1 metre of a hot water appliance is insulated.

3. Notwithstanding the above, the cupboard temperatures are normally higher than in a conventional system and therefore the design of both the cupboard and the door should take this into account.
4. The system operates on the normal primary flow and return temperatures (i.e. 82°C flow and 71°C return) of the boiler and should be installed and balanced in exactly the same way as any traditional hot water radiator or convector system.
5. All BoilerMate III models are for use with an open vented primary central heating system.

Combined Feed and Expansion Cistern

1. It is most important to adjust the fitted ballvalve whilst the system is cold to give a water level of 50mm above the feed outlet to the primary system. This is to allow adequate room for expansion, and the level is marked by a corrugation in the wall of the tank.
2. A minimum of 225mm should be left above the unit to allow access to the ballvalve for servicing and adjustment in accordance with the Model Byelaws.

3. A 22mm compression fitting is provided as standard in the feed and expansion cistern for the overflow/warning pipe, which should be no less than 20mm internal diameter.
4. The overflow/warning pipe should be fitted to discharge clear of the building and be sited so that any overflow can be easily observed.
5. The overflow/warning pipe should be installed in a material suitable for use with heating feed and expansion cisterns in accordance with BS 5449 and should not have any other connections to it.




Figure 3.1 Typical arrangement of pipework in cylinder cupboard.

Plumbing Connections

1. Make all water connections in accordance with the labelling on the thermal store and the associated pipework as shown in Figure 3.1.
2. If a boiler is fitted above the thermal store, a gravity check valve should be incorporated in the connecting pipework leading from the BoilerMate III to the boiler i.e. the boiler return.
3. All factory made joints should be checked after installation in case they have been loosened during transit.

INSTALLATION

Domestic Hot Water Temperature

The electronic control system automatically regulates the domestic hot water outlet temperature to approximately 52°C and no adjustment or setting is necessary during installation.

The Boiler Thermostat

This should always be set to **maximum** to give the best hot water and heating service and to achieve the highest efficiency and reduced boiler cycling by ensuring that the store thermostat will then be controlling the boiler.

Range Rated Boiler

When a range rated boiler is used it should always be set at the **highest** output. The system efficiency will not be impaired while the recovery rate will be improved.

Pump Settings / Replacement

1. The boiler/system pump should be set at a speed at which the temperature difference across the boiler is not greater than 10°C. This adjustment should be made when the space heating is off.
2. The domestic hot water plate heat exchanger pump should always be set at maximum speed.
3. If it is necessary to replace either of the two pumps fitted to the appliance the pump head (motor pack) only should be removed as recommended by the manufacturer (Grundfos). Assuming it is within warranty this will be accepted by a merchant as being under warranty as long as a complete pump i.e. alleged faulty motor pack and new base is left with the merchant. It is important when a pump has been replaced to ensure that any air is adequately vented.

INSTALLATION IN TEN EASY STEPS

BoilerMate III installation is easier and quicker than a conventional vented system because there is no secondary feed and expansion cistern to install and no time is wasted in planning and installation of the controls and pumps in the cylinder cupboard.

1. Inspect the position in which BoilerMate III is to be fitted and check that the internal depth is at least 550mm and the width is 700mm for the model BM120, 600mm deep and 715mm wide for the model BM140 and 650mm deep and 770mm wide, for the BM180, BM200 and BM220 models. (See Figures 1.6 and 3.1).
2. Plan the pipe connections. Each fitting on the BoilerMate III has its own label. You need to connect the following pipes: -
 - a) Pumped flow and return pipes from the body of the BoilerMate III to the radiators.
 - b) Pumped flow and return pipes from the body of the BoilerMate III to the boiler.
 - c) Cold mains water supply connections to the inlet side of the plate heat exchanger and to the ball valve in the F & E cistern.
 - d) Domestic hot water supply pipe from the plate heat exchanger outlet to the taps.
 - e) Overflow/warning pipe from the F & E cistern to discharge in a conspicuous position externally.
3. If you are fitting the cistern remotely, check the route of the 22mm diameter open safety vent pipe and of the 15mm diameter feed and expansion pipe from the BoilerMate III to the cistern position. Also check the route of the overflow/warning pipe. All the BoilerMate III connections are clearly labelled.

When you have decided where the pipes are to be run, check the space for them inside the BoilerMate III compartment.

4. Decide at what stage in your installation work you are going to fit the BoilerMate III. We would suggest that the BoilerMate III should be fitted first and the pipes run from it to the boiler, radiators and domestic hot water supply system subsequently in that order. If the BoilerMate III is installed early in the construction process ensure it is adequately protected or removed and refitted later. If it is decided to install the BoilerMate later in the construction process, the first fix pipework should enter the cylinder cupboard as shown in Figure 3.1
5. Remember that the automatic heating system bypass is already fitted and no additional bypass should be fitted in the system.
6. Carry out the rest of the installation work, i.e. boiler radiators and hot water supply pipework. Connect the cold water supply pipework.
7. Fill the BoilerMate III, radiators, boiler and pipework with water through the F & E cistern. Adjust the ball valve so that when cold the water shuts off at, or just below, the level mark on the side of the cistern. Flush the system out, fill and vent again.

8. Open the domestic hot water isolating tap and establish flow through the taps etc. Check that the flow through all hot and cold water taps etc. is stopped when the mains water stop valve is closed.
9. The system now requires to be electrically connected.
10. The system is now ready to be commissioned.

WIRING THE SYSTEM

The BoilerMate III is pre-wired to a central control panel (see page 18), and plumbers are well able to complete the electrical installation provided they adhere strictly to the IEE Regulations.

Note: Do not attempt the electrical work unless you are competent to carry it out to the above standards.

Fused Isolator

1. Connection to the electrical supply must allow complete electrical isolation by installing a double pole switch having a 3mm separation on both sides.
2. The isolating switch must only serve the BoilerMate III space heating and hot water system together with its controls and must be located within 1 metre of the appliance.
3. The supply to the BoilerMate III must be fused at 3A.
4. A green power indicator is provided on the front of the unit.

To Wire the BoilerMate

Before commencing, ensure that the power source to which the BoilerMate is to be connected is isolated. The generic wiring procedure for the BoilerMate is described below.

1. Remove the white cover plate (4 screws) and run the external wiring through the grommets provided at the bottom of the white control panel.
2. From 3A fused and switched connection unit wire the mains power supply to the BoilerMate III storage appliance control PCB as follows:

- 'Live' to terminal '1'
- 'Neutral' to terminal '2'
- 'Earth' to terminal '3'

Note: The mains power supply to the domestic hot water temperature control PCB is already connected to the storage appliance control PCB.

3. Wire the boiler to the BoilerMate storage appliance control PCB as follows: -

- Take a 'Live' from the BoilerMate PCB terminal '5' to boiler 'Switched Live' terminal.
- Take a 'Neutral' from the BoilerMate PCB terminal '7' to the boiler 'Neutral' terminal.
- Take an 'Earth' from the BoilerMate PCB terminal '6' to the boiler 'Earth' terminal.
- If the boiler requires a permanent live other than for a pump over-run, then this should be taken from terminal '4' on the BoilerMate PCB.

4. The link between BoilerMate PCB terminals '25' and '28' should be removed if a room thermostat is to be fitted.
5. The link between BoilerMate terminals '22' and '24' should be removed if a remote single channel programmer is to be fitted for controlling space heating only.
6. The link between the terminals '22' and '23' and the link between terminals '23' and '24' should be removed if an extra single channel clock or a dual channel programmer is to be fitted for controlling both space heating and hot water.
7. When the wiring is complete, replace the front cover plate (4 screws).

INSTALLATION

CONTROL WIRING DIAGRAM

Jumpers SAC PCB




1_ON 2_OFF 3_ON

4_ON: 180s pump overrun

5_OFF

A_ON Horizontal

B_ON Horizontal



NOTE

If no clock programmer is fitted a link will also be provided in terminals 23 and 24.

The power on indicator light is wired in terminals 5 & 6 on the domestic hot water control P.C.B.


INSTALLATION

To Wire the Room Thermostat

1. Remove the link joining the BoilerMate control PCB terminals '25' and '28', and wire the room thermostat to the BoilerMate III as follows:
 - From the BoilerMate PCB terminal '25' take a 'live' to the 'live' connection on the room thermostat.
 - From a room thermostat 'switched live' connection take a 'live' to BoilerMate PCB terminal '28'.
 - Connect the BoilerMate PCB terminal '27' to the room thermostat 'Neutral' terminal.
 - If required, connect the BoilerMate PCB terminal '26' to the room thermostat 'Earth' terminal.

Frost Protection

1. When frost protection is required for the whole house or where a base temperature is required during cold weather, then a frost thermostat should be wired across BoilerMate PCB terminals '22' and '28'.
2. An alternative to fitting a frost thermostat would be to set the programmer to constant during the cold weather period, and adjust the room thermostat to a suitable setting.
3. When frost protection is required for the boiler circuit only a change over type pipe thermostat should be fitted on the primary return pipe adjacent to the boiler and wired as shown below.
4. If a two channel clock is fitted and frost protection is required for the boiler circuit only, then the frost thermostat should be wired across BoilerMate PCB terminals '22' and '23'.



Delay Timer

This facility is provided within the system control appliance control PCB.

OVERNIGHT SHUT DOWN

The most effective service from the thermal storage system (BoilerMate III) is achieved when the boiler is on demand for twenty four hours under the control of the store thermostat.

In special circumstances the system can be wired to isolate the boiler overnight using one of the methods described below.

Using Two Single Channel Programmers

This method is suitable if the BoilerMate III is already fitted or supplied with a space heating programmer e.g. Single channel Grasslin. The second single channel programmer is wired by removing the link between terminal 22 and 23 and taking the switched live to terminal number 23. The live neutral and earth connections can be taken from terminals 22, 20 and 21 respectively if required. The second single channel programmer can then be set to shut down the appliance overnight.

Using a Two Channel Programmer

If the BoilerMate III is supplied as a no clock option, then a remote two-channel programmer can be used.

This should be wired with the HW output wired to terminal 23 and the heating output wired to terminal 24.

COMMISSIONING

COMMISSIONING THE SYSTEM

It is essential that the system functions properly for optimum performance. To achieve this, the primary system should be commissioned in accordance with good practice and generally in accordance with the requirements of BS6798, BS5449 and BS7593: 1992.

Cleansing the Primary System

1. Ensure that the float is correctly adjusted to close the ballvalve at the water level line inside the F & E cistern.
2. Fill the system and flush cold.
3. Refill the system.
4. Add a cleanser such as Sentinel X300 or Fernox Superfloc to ensure that flux residues and installation debris are removed from the system. (***When determining the quantity of cleanser required, be sure to allow for the increased volume of water in the primary circuit due to the thermal store - see Table 1.1 for volumes.***)
5. In most cases the following quantities will be adequate for a typical 3/4 bedroom property.

Model	Volume to be added to the system (litres)	
	Cleansing agent	
	Sentinel X300	Fernox Superfloc
BM120	1¼	5
BM140	1½	6¼
BM180	2	7½
BM200	2¼	9
BM220	2½	9¾

When using either cleansing or corrosion inhibitor chemical, the manufacturers instructions must be followed.

6. Commission the boiler.
 - a) If the boiler is range rated, then adjust it to the **maximum** heat input.
 - b) Set the boiler/system pump speed so that the temperature difference across the boiler is **less than 10°C**.
 - c) Set the boiler thermostat to maximum.
7. To ensure full cleansing, circulation to all parts of the system should continue for a minimum of 1 hour.
8. Flush the system hot having checked that there is no overflow when the system is up to temperature.

9. Refill the system.
10. Switch on and check the operation of the immersion heater (if fitted).
11. Ensure that the 3 port motorized valve is in Auto position (i.e. not in manual locked position).
12. Ensure that the automatic bypass valve is set correctly to give approximately 10oC temperature rise across the boiler when the space heating is on.

Primary Water System Treatment

1. Although the standard BoilerMate III has no special water treatment requirements, the radiators and other parts of the circuit will benefit from the application of a scale and corrosion inhibitor such as Sentinel X100 or Fernox MBI.
2. When determining the quantity of inhibitor required, be sure to allow for the increased volume of water in the primary circuit due to the thermal store- see Table 1.1 for volumes.
3. In most cases the following quantities will be suitable for a typical 3/4 bed property.

Model	Volume to be added to the system (litres)	
	Corrosion inhibitor agent	
	Sentinel X100	Fernox MB1
BM120	1¼	1¼
BM140	1½	1½
BM180	2	2
BM200	2¼	2¼
BM220	2½	2½

When using either cleansing or corrosion inhibitor chemical, the manufacturers instructions must be followed.

Peel and paste 'boiler thermostat' label on suitable prominent location on the boiler.

Cleansing Hot/ Cold Water System Treatment

1. Fully flush and chlorinate the hot and cold water system in accordance with the recommendations in the Model Water Byelaws and BS6700.
2. Before finally filling the system check and clean the filter basket in the Y type strainer.

COMMISSIONING

DESCRIPTION OF DIAGNOSTIC DISPLAY AND CONTROLS

A brief description of the functions of the diagnostic display and controls is provided below. The details of the individual functions are described in the appropriate sections of this document. LED = light emitting diodes.

Green LEDs 1 – 10:

- a) The 'Green LED's 1-10' indicate the temperature of the water in the store. When the store temperature is below the minimum pre-set value, 'LED-1' will flash. When the store temperature is higher than the maximum pre-set value, LED-10 will flash.
- b) One or more 'Green LED's' together with a permanently 'ON Red LED-14' also indicate a type of fault in the system.

Orange LED-11

- a) The 'Orange LED-11' when constantly 'ON' indicates a demand for space heating from the programmer and room thermostat.
- b) The 'Orange LED-11' when 'FLASHING' indicates a demand for space heating from the programmer and room thermostat AND the boiler is in the firing mode.

Orange LED-12


- a) The 'Orange LED-12' when constantly 'ON' indicates that the store sensor is satisfied but the programmer (if fitted) is on timed hot water mode.
- b) The 'Orange LED-12' when 'FLASHING' indicates a demand for hot water from the store sensor, the programmer (if fitted) is in timed hot water mode AND the boiler is in the firing mode.

Red LED-14

- a) The 'Red LED-14' when 'FLASHING' indicates that the system is in the 'SET UP' mode and is ready to receive data from the user.
- b) The 'Red LED-14' when constantly 'ON' together with one or more 'Green LEDs 2-9' indicate a type of system fault.

Push buttons '+', '-', and 'Set'

These buttons are used to change and set the hot water store temperature and other parameters.



COMMISSIONING

COMMISSIONING THE DIRECTLY HEATED STORE TEMPERATURE SETTING

For maximum system efficiency the store thermostat must be in control of the boiler i.e. the boiler cycles on the store thermostat and not on its integral thermostat.


The control system in this appliance has been programmed to automatically commission the store thermostat setting in accordance with pre-set default values.

However matching the control settings to the installed boiler can further enhance the performance of the system.

- a) **Ensure that the boiler thermostat is set at maximum.**
- b) Ensure that the space heating is switched 'Off' on the programmer i.e. the 'Orange LED-11' is 'Off'.
- c) Ensure that the domestic hot water is switched 'On' on the programmer if fitted i.e. the 'Orange LED-12' is 'On'.
- d) Leave the appliance to heat up. At this stage Green LED 1 and Orange LED 12 will flash.
- e) As the store rises in temperature the Green LED's will progressively switch 'ON' and Orange LED 12 will continue to flash.

- f) When the store is satisfied Orange LED 12 will stop flashing (but remain 'ON') and the boiler will switch off.
- g) Draw off just enough hot water for the boiler to re-fire.
- h) Whilst the boiler is still firing put the system control into the commissioning mode by pressing the three push buttons marked '-', '+' and 'Set' simultaneously until the 'Red LED-14' begins to flash.
- i) When the boiler switches 'Off' press the push buttons marked '-' and '+' simultaneously until the 'Red LED-14' switches off.
- j) The system is now commissioned to match the installed boiler and nearly all the Green LED's will be 'on'
- k) If after this procedure the 'Red LED-14' and the 'Green LED-9' are permanently on then the boiler is not delivering water at a high enough temperature. Check boiler and boiler thermostat setting and repeat the commissioning procedure.

Note: If an attempt is made to commission the system below the minimum pre-set store temperature, then a fault will be indicated (see 'k' above) but the system will continue to work at the present values.



COMMISSIONING

IMPORTANT DO'S AND DON'TS

1. **DO** check the incoming mains water pressure. The preferred range of mains pressure is 2 – 3bar.
 2. **DO** check that all connections are in accordance with the labelling on the thermal store.
 3. **DO** adjust the ballvalve so that the water level in the F & E cistern when the system is cold is at or just below the level mark inside the cistern.
 4. **DO** make sure that there is adequate clearance above the F & E tank to service the ballvalve.
 5. **DO** ensure that the range rated appliances are set at the **highest output** and the boiler thermostat is set to **maximum** for all boilers.
 6. **DO** ensure that the water level in the expansion cistern is at least 250mm above the highest point on the radiator circuit or the highest point of the system.
 7. **DO** insulate any exposed pipework in the BoilerMate cupboard.
 8. **DO** plumb the overflow/warning pipe in a 20mm internal diameter pipe material which is suitable for use with a heating F & E cistern, in accordance with BS 5449 (such as copper) and ensure it discharges in a conspicuous external position.
 9. **DO** check the pump settings.
 - a) The boiler/system pump should be set to give a temperature difference across the boiler of 10°C or less.
 - b) The hot water plate heat exchanger pump should be set at **maximum**.
 10. **DO** ensure that the filter basket in the Y type strainer is removed cleaned and replaced prior to handover of the system.
 11. **DO** ensure that the 3 port valve is in Auto position.
 12. **DO** ensure that the bypass valve is set correctly.
 13. **DON'T** use a combined feed and vent on BoilerMate installations.
 14. **DON'T** use a BoilerMate on a sealed primary i.e. closed system.
 15. **DON'T** use pipe smaller than 28mm between the boiler and the BoilerMate when the boiler rating exceeds 20kW (about 68,000 Btu/h).
 16. **DON'T** use dipped flow and return between the boiler and the BoilerMate unless the boiler is fitted with an overheat thermostat. If necessary check with the suppliers.
- NOTE:** If an attempt is made to commission the system below the minimum pre-set store temperature, then a fault will be indicated and the system will continue to work in accordance with the pre-set default values.

FAULT FINDING/DIAGNOSTICS

FAULTS AND THEIR CAUSES

Any fault in the system design and malfunction of system components will generate customer complaints. These complaints can be grouped into the following three main categories: -

- a) The system is noisy
- b) Hot water service is unsatisfactory
- c) Space heating is unsatisfactory

Causes of a 'Noisy' System

1. Noisy pump operation
 - a) Check the level of water in the F & E cistern – adjust and vent the pump/system if necessary.
 - b) Check the pump speed setting of the system/boiler pump – reduce if necessary but ensure that the temperature rise across the boiler does not exceed 10°C.
 - c) If system is noisy when in heating mode – check and adjust if necessary the heating system bypass valve.
 - d) Check that the radiators are correctly balanced.
2. Noisy boiler operation
 - a) Check the flow rate through the boiler at full gas rate by measuring the temperature rise across the boiler. If the temperature rise is greater than 10°C, then increase the pump speed.
 - b) Check the level of water in the F & E cistern and the working head on the boiler.
 - c) Check and vent the system if necessary.
3. Noise when hot water tap is opened
 - a) If the plate heat exchanger pump is noisy when the hot water tap is opened, then check the level of water in the F & E cistern and vent the pump if necessary.
 - b) Water hammer – loose pipe work and/or tap washers.

Causes of 'Unsatisfactory Hot Water Service'

- a) Check boiler thermostat – this should be set at maximum.
- b) Check that the boiler flow temperature is adequate when it is switched off by either the internal or store thermostat – it should not be less than 80°C.
- c) If a separate hot water programmer or a two channel programmer is fitted, then check that the hot water 'on time' periods are set correctly to match the demand pattern in a dwelling.

- d) Check that the store is charging to at least 75°C – if not then recommission.
- e) Check that the hot water plate heat exchanger pump stops and starts when the hot water tap is opened and closed.
- f) Check that the plate heat exchanger pump is set at maximum speed.
- g) Check that the hot water outlet temperature does not change significantly when the hot water flow rate is increased from say 5l/min to 15l/min.
- h) Check that the filter before the flow switch is not blocked – clean if necessary.
- i) Check that the space heating and hot water load is not greater than the boiler output and that the BoilerMate III model is suitable for the type of dwelling.
- j) If 'a' to 'i' are correct then it is possible that the performance of the heat exchanger is impaired by scale. In this case the hot water flow rate will be noticeably less than the cold water flow rate. Replace it with a factory exchange unit and re-check hot water performance.

Causes of 'Unsatisfactory Space Heating'

- a) Check the boiler thermostat – this should be set at maximum.
- b) Check that the boiler flow temperature before it is switched off by its internal or the store thermostat is adequate – it should not be less than 80°C.
- c) Check the operation and the settings of the heating programmer and the room thermostat.
- d) Check that the 3-port flow share valve is functioning and that the system/boiler pump is circulating the water to the radiator circuit.
- e) If some rooms are not being heated properly, then balance the system.

Overflow From Feed & Expansion Cistern

- a) Check that the controlled level of water in the cistern is no higher than the indentation mark. Adjust if necessary.
- b) If replacement ballvalve is required, then this should be obtained only from Gledhill Water Storage Ltd.


FAULT FINDING/DIAGNOSTICS

SYSTEM FAULT INDICATION AND DIAGNOSTICS

The SAC control PCB does not control or override any safety controls of the heating system.

The SAC control PCB detects the faults in the system and these are displayed on the LED display panel.

Even when the SAC control PCB is in the fault indication mode i.e. when the RED LED-14 is continuously 'ON', the heating system will continue to function although all the services may not be available or will only be available at lower level and efficiency.



Fault Indication table (Diagnostic display)	
LEDs ON	Fault
Red 14 + Green No3	Store sensor not connected – system will not function
Red 14 + Green No 5 + Orange No 13 ON when no hot water tap is opened.	Domestic hot water flow switch stuck in the closed position i.e. hot water heat exchanger pump is permanently ON.
Red 14 + Green No 9	Boiler not delivering water at required temperature – check boiler thermostat
Further Information on Faults <ul style="list-style-type: none"> Further faults relating to the Pump Speed Controller are indicated on the PCB and these are described in detail on the following pages. Further faults relating to the Storage Appliance Controller are indicated on the SAC PCB and these are also described in detail on the following pages. 	

Clearing the Faults

It is important that the system is reset after the faults have been rectified. The procedure for clearing the fault registers is:


- Press the two push buttons marked '+' and 'Set' simultaneously until the 'RED LED-14' starts to 'flash'.
- Press the push button marked 'Set' until the 'RED LED-14' switches off. The Green LEDs will now indicate the store temperature.

It is impossible to reboot the Store Appliance Controller to clear it and re-establish the default conditions. Please speak to our Technical Sales Office if you consider this to be necessary.

FAULT FINDING/DIAGNOSTICS

DHW PUMP SPEED CONTROL PCB

The layout of the pump speed control PCB is shown in the figure below.




Function Indicating LED

Off:	No mains power supply - check fuse
Flashing - Low frequency:	System status is OK
Flashing - High frequency:	Temperature measurement error - check sensor or wiring
On - Permanent:	Processor related fault - no control of hot water - change board

FAULT FINDING/DIAGNOSTICS

STORAGE APPLIANCE CONTROL PCB (SAC)

The layout of the SAC PCB is shown in the figure below and is designed to control all the operations of the appliance.



LEDS - when ON

LED_1 Indicates that there is mains voltage (230V, 50Hz) at terminal '5' i.e. the boiler is ON.

LED_2 Indicates that there is mains voltage (230V, 50Hz) at terminal '10' i.e. the boiler/system pump is ON.

LED_3 Indicates that there is mains voltage (230V, 50Hz) at terminal '13' i.e. the 3 port flow share valve connected to terminals 11, 12 and 13 is ON - heating and hot water (i.e. mid position).

LED_4 Indicates that there is mains voltage (230V, 50Hz) at terminal '13 and 14' i.e. the 3 port flow share valve connected to terminals 11, 12, 13 and 14 is ON - heating only.

CONNECTIONS

The front display panel is connected into C1. The PSC PCB is connected to terminals 20, 21 and 23.

JUMPERS



Should be in accordance with the details on page 18.

APPENDIX

WATER SAVINGS

WATER RELATED COSTS CAN BE REDUCED BY GOOD PLUMBING PRACTICE.

TAPS & MIXERS



Vast quantities of water are needlessly run off to waste due to Taps, Mixers and Showers discharging flow rates far in excess of the rates required for them to perform their duties.


The contrasting flow rates shown on this leaflet clearly illustrate the savings that can be made whilst still providing a good performance.

British made AQUAFLOW REGULATORS provide constant flow rates by automatically compensating for supply pressure changes between 1 bar & 10 bars.

To facilitate installation into the wide range of plumbing equipment which is encountered in the U.K, FOUR FIXING OPTIONS are available:-


OPTIONS FOR SHOWERS

1. MXF "DW" RANGE - For fitting behind Fixed Shower Heads or onto Flexible Hoses for Handshowers (preferably onto the inlet end when lightweight hoses are used).
2. COMPRESSION FITTING RANGE. "In Line" regulators as in Option 4 for Taps & Mixers.



4 FIXING OPTIONS FOR

1. MK RANGE - Combined Regulators & Aerator for screwing onto Taps & Mixers with internal or external threads on their noses. Anti Vandal models also available.
2. MR05-T RANGE - Internal Regulators. Push fit into Tap or Mixer seats. Produced in three sizes - 12.5mm (BS1010), 12mm & 10mm, Flangeless models also available for Taps with Low Lift washers.
3. MXF STANDARD RANGE - Screw on tail models for Taps & Mixers. Fix onto the tails before fitting the tap connectors. Available in 3/8", 1/2", 3/4" and 1" BSP.
4. COMPRESSION FITTING RANGE - "In Line" regulators housed in 15mm & 22mm CXC COUPLERS & ISOLATING VALVES. " " UK WFBS LISTED BY THE WATER RESEARCH CENTRE. Isolation valves available for slotted screwdriver operation or with coloured plastic handles. Now available also in plastic bodied push-fit couplers & valves.



Information by courtesy of













AQUAFLOW REGULATORS LTD

Haywood House, 40 New Road, Stourbridge, West Midlands DY8 1PA

Telephone (01384) 442611 Fax: (01384) 442612

SHORT PARTS

Key No.	Description	Manufacturer	Stock Code No.	Gas Council Part No.
1	Ball float		FT429	
2	Ballvalve		FT207	
3	22mm ball-o-fix valve		GT024	
4	Y type strainer		XB314	
5	3/4" F/F single check valve		GT041	
6	Grundfos 15/50 pump with 1" connections		GT105	
7	Grundfos 15/50 pump with 1 1/2" connections		XB001	
8	22mm ball type pump valve		XB121	
9	28mm ball type pump valve		XB122	
10	Flow switch		GT106	
11	Plate heat exchanger		GT017	
12	Store appliance controller SAC		GT151	
13	Store sensor		GT149	
14	Pump speed controller PSC		GT152	
15	Pump speed sensor		GT153	
16	Grasslin electro-mechanical clock		XB215	
17	Grasslin digital clock		XB216	
18	22mm 3 port mid position valve	Danfoss HS3B	XG130	
19	28mm 3 port mid position valve	Danfoss HS3B28	XG142	
20	Grundfos 15/60 pump		XB241	
21	22mm By-pass valve		XG156	
22	L.E.D. Display panel		GT150	
23	Water mixing valve - Brawa		XC007	



Gledhill (Water Storage) Ltd

AMD, MAY 2007
CONDITIONS OF SALE & WARRANTY TERMS

1. We only do business upon the Conditions which appear below and no other. Unless we so agree in writing these Conditions shall apply in full to any supply of goods by us to the exclusion of any Conditions or terms sought to be imposed by any purchaser. These Conditions of Sale and Warranty Terms override those which are contained on the Invoice Forms and all Sales are now subject to these Conditions of Sale and Warranty terms only.

2. PRICE

Once an order or call off has been accepted the price will be held for three months but if delivery is extended beyond that period at the customer's request, then we reserve the right to amend the price when necessary. The company reviews its pricing annually to adjust for changes in our cost base. We reserve the right to alter prices at any time for severe movements in raw materials (mainly copper and steel). If there is to be a change we will give customers at least four weeks notice but anything delivered after that date will be at the revised price. An order may not be cancelled or varied after acceptance without the written consent of the company. Such cancellation or variation shall be subject to such reasonable charges as may be appropriate.

3. SPECIFICATION

The goods are supplied in accordance with the Specifications (if any) submitted to the Purchaser and any additions and alterations shall be the subject of an extra charge. Any goods not so specified shall be in accordance with our printed literature or the literature of any of our component suppliers (subject to any modifications made since publication). If we adopt any changes in construction or design of the goods, or in the specification printed in our literature, the Purchaser shall accept the goods so changed in fulfilment of the order.

4. PAYMENT

The invoice price of goods shall be payable within 30 days of despatch by us of our invoice for the goods or such longer time as may be stated by our quotation or invoice. If we receive payment in full on or before the due date we will allow an appropriate settlement discount except where we have quoted a special net price. If payment is not received in full on or before the due date we shall be entitled in addition to the invoice price to:

- (i) payment of a sum equal to any increase in the copper price supplement applicable to the particular goods sold between the date of receipt of order and the date of receipt of payment in full; and
- (ii) interest on any part of the invoice price unpaid after the due date at the rate of 3% per annum over the base rate for the time being of HSBC Bank plc.

5. TIME

We give estimates of delivery dates in good faith and time of delivery is not nor shall be made of the essence of any contract nor shall we be liable for any loss or damage occasioned by delay in delivery.

6. DELIVERY

We deliver free normally by our own vehicles within 25 miles of any of our manufacturing depots. Delivery to any place more than 25 miles from one of our manufacturing depots may be subject to our quoted delivery charges. We reserve the right to make delivery of goods contained in one order by more than one consignment and at different times. Where a period is agreed for delivery and such period is not extended by our Agreement, the Purchaser shall take delivery within that period. If the Purchaser fails to take delivery, we shall be entitled at the Purchaser's risk and expense to store the goods at the Purchaser's premises or elsewhere and to demand payment as if they had been despatched. Off loading at point of delivery shall be the responsibility of and be undertaken by the Purchaser.

7. SHORTAGES OR DAMAGE

Goods must be inspected before signature of delivery note and any damage, shortage or discrepancy noted on the delivery note and the goods returned on the same vehicle. The buyer must also give us immediate written notice of the damage, shortage or discrepancy so that we may prompt investigation.

8. RETURN OF GOODS

Goods may not be returned to the Company except by prior written permission of an authorised officer of the Company and such return shall be subject to payment by the Purchaser of handling and re-stocking charges, transport and all other costs incurred by the Company.

9. COMPANY LIABILITY

All our goods are made of the best materials from reputable manufacturers and where stated are manufactured to the appropriate British or European Standard. Complaints must be given to us immediately, before any action is taken, as responsibility cannot be accepted if repairs or renewals are attempted on site without our written authority.

Defects caused by corrosion or scale deposits are not covered by this guarantee save as expressly provided in paragraph (f) of this Condition 9.

Where we agree to rectify any defect, we reserve the right to undertake the work on our own premises.

The following guarantee covers faulty materials and manufacture for the stated period, provided that:-

- The unit has been installed in accordance with our installation and service instructions and all relevant codes of practice and regulations in force at the time of installation.
- That all necessary inlet controls and safety valves have been fitted correctly.
- It has only been used for the storage of potable water supplied from the public mains.
- Where appropriate the unit has been regularly maintained as detailed in the installation and service instructions.

(a) Domestic and Commercial Open Vented Cylinders and Tanks.

The copper storage vessel is guaranteed for ten years and if it proves to be defective either in materials or workmanship, we will either repair or supply replacement at our option with the closest substitute in the case of any obsolete product to any address in Great Britain.

- (i) free of all charge during the first year after delivery by us.
- (ii) thereafter at a charge of one-tenth of the then current list price and any copper price supplement and delivery charge during the second year after delivery by us and increasing by a further one-tenth on the second and subsequent anniversary of delivery by us.

(b) Domestic Mains Fed Products (Primary Stores)

The copper storage vessel is guaranteed for five years and if it or any integral pipework as part of the storage vessel assembly proves to be defective either in materials or workmanship, we reserve the right to either repair or supply replacements or the closest possible substitute in the case of any obsolete product and will collect and deliver to any address in England, Wales and Scotland (excluding all Scottish Islands).

- (i) free of all charge during the first year after delivery by us.
- (ii) thereafter at a charge of one-fifth of the then current list price or any copper price supplement and delivery charge during the second year after delivery by us increasing by a further one-fifth on the second and subsequent anniversary of delivery by us.

(c) Integrated Boiler and Storage Vessel Products and Stand Alone Boilers

In the case of the GulfStream range of products and the Gledhill boiler range of products, Gledhill guarantees the heat exchanger (boiler) for material and construction faults for two years and FURTHER we will meet the installer/contractors reasonable costs in removing and replacing any DEFECTIVE heat exchanger up to a MAXIMUM of one third of the extent of our liability in regard to the replacement product. THE RESPONSIBILITY FOR THE EXECUTION OF THIS GUARANTEE LIES WITH THE INSTALLER.

The guarantee becomes null and void if the appliance is used incorrectly, or in the event of proven negligence or incorrectly implemented repairs OR FAILURE TO CARRY OUT THE RECOMMENDED INSPECTION/MAINTENANCE. The guarantee also becomes null and void if changes are made to the appliance without our knowledge, or if the serial number on the appliance is removed or made illegible.

The annual service must be carried out by a competent installer in accordance with the advice given by Gledhill and using Gledhill approved parts.

(d) Stainless Steel Unvented Cylinders

Gledhill guarantee the components including controls, valves and electrical parts for two years from the date of purchase. IT SHOULD BE NOTED THAT THE FACTORY FITTED TEMPERATURE AND PRESSURE RELIEF VALVE MUST NOT BE REMOVED OR ALTERED IN ANY WAY OR THE GUARANTEE WILL NOT BE VALID. GLEDHILL WILL NOT BE RESPONSIBLE FOR ANY CONSEQUENTIAL LOSS OR DAMAGE HOWEVER IT IS CAUSED.

The guarantee for the stainless steel vessel is for twenty five years if the original unit is returned to us AND PROVIDED THAT:

- (i) It has been installed as per the Design, Installation & Servicing Instructions, relevant standards, regulations and codes of practice.
- (ii) It has not been modified, other than by Gledhill.
- (iii) It has not been subjected to wrong or improper use or left uncared for.
- (iv) It has only been used for the storage of potable water.
- (v) It has not been subjected to frost damage.
- (vi) The benchmark log book is completed after each annual service.
- (vii) The unit has been serviced annually.

It should be noted that the guarantee does not cover:

- the effects of scale build up
 - any labour charges associated with replacing the unit or parts.
- If the stainless steel vessel proves to be defective either in materials or workmanship we reserve the right to either repair or supply replacements or the closest possible substitute in the case of any obsolete product and will collect and deliver to any address in England, Scotland and Wales (excluding all islands):

- (i) free of charge during the first year after delivery by us.
- (ii) thereafter at a charge of one twenty fifth of the then current list price during the second year after delivery by us and increasing by a further one twenty fifth on the second and subsequent anniversary of delivery by us.

ACTION IN THE EVENT OF FAILURE

If the Stainless Lite develops a leak we will ask for a deposit against the supply of a new one. This will be refunded if the failure is within the terms of the warranty when it has been examined by us.

(e) Solar Panels and ancillary equipment

Gledhill provides a five year warranty for defects in the collectors (except broken glass and collector accessories eg metal edgings). If the collector demonstrably fails to meet one of the requirements of the standard DIN 4757 part 3 we will replace it free of charge based on the date of invoice. We can not be responsible for damage caused by mechanical stress and/or changes caused by weather related influences. The warranty excludes minor surface damage that does not affect performance or malfunction due to improper assembly or installation.

Please note:

- Installation must have been carried out by a licensed specialized company (heating contractor or plumber) following the version of installation instructions in force.
- Gledhill or its representative was given the opportunity to check complaints on site immediately after any defect occurred.
- Confirmation exists that the system was commissioned properly and that the system was checked and maintenance was performed annually by a specialised company licensed for this purpose.

(f) Components of our products other than Storage Vessels and Integral Pipework.

We will either extend to the purchaser the same terms of warranty as we are given by the manufacturer of the component or if the manufacturer does not give any warranty, replace free of charge any component which becomes defective within two years after the date of the delivery by us and is returned to us at the purchaser's expense but we shall not meet the cost of removal or shipping or return of the component or any other cost charges or damages incurred by the purchaser.

If the appliance manufactured by Gledhill incorporates a factory fitted scale inhibitor then during the period of three years from the date of delivery Gledhill will replace, free of charge, any plate heat exchanger fitted in the appliance as original equipment in which scale formation occurs that materially reduces the effectiveness of the plate heat exchanger. This guarantee does not extend to any other component installed within the Gledhill appliance or elsewhere in the Purchaser's domestic water system.

(g) General

In the case of goods manufactured solely in accordance with our specification and designs and in respect of any installation work carried out by or on our behalf, our entire liability and the purchaser's sole remedies (subject to (a) - (f) above) and shall be as follows:

(a) we accept liability for death or personal injury to the extent that it results from our negligence that of our employees agents or subcontractors.

(b) subject to paragraph (d) below, we accept liability for direct physical damage to tangible property to the extent that such damage is caused by our negligence that of our employees agents or subcontractors.

(c) our total liability to the purchaser over and above any liability to replace under (1) - (4) above (whether in contract or in tort including negligence) in respect of any one cause of loss or damage claimed to result from any breach of our obligations hereunder, shall be limited to actual money damages which shall not exceed £20,000 provided that such monetary limit shall not apply to any liability on the part of ourselves referred to in paragraph (a) above.

(d) except as provided in paragraph (a) above but otherwise notwithstanding any provision herein contained in no event shall we be liable for the following loss or damage howsoever caused and even if foreseeable by us or in our contemplation :-

(i) economic loss which shall include loss of profits, business revenue, goodwill or anticipated savings.

(ii) damages in respect of special indirect or consequential loss or damage (other than death, personal injury and damage to tangible property).

(iii) any claim made against the purchaser by any other party

(save as expressly provided in paragraph (b) above).

(e) except in respect of our liability referred to in paragraph (a) above no claim may be made or action brought (whether in contract or in tort including negligence) by the purchaser in respect of any goods supplied by us more than one year after the date of the invoice for the relevant goods.

(f) nothing in these Conditions shall confer on the purchaser any rights or remedies to which the purchaser would not otherwise be legally entitled.

10. LOSS OR INJURY

Notwithstanding any other provision contained herein the Purchaser's hereby agree to fully indemnify us against any damages losses costs claims or expenses incurred by us in respect of any claim brought against us by any third party for :-

(a) any loss injury or damage wholly or partly caused by any goods supplied by us or their use.

(b) any loss injury or damage wholly or partly caused by the defective installation or sub-standard workmanship or materials used in the installation of any goods supplied by us.

(c) any loss injury or damage in any way connected with the performance of this contract.

PROVIDED that this paragraph (6) will not require the Purchaser to indemnify us against any liability for our own acts of negligence or those of our employees agents or sub-contractors.

FURTHER in the case of goods supplied by us which are re-sold to and installed by a third party by the Purchaser it will be the sole responsibility of the Purchaser to test the goods immediately after their installation to ensure that inter alia they are correctly installed and are in proper working order, and are not likely to cause any loss injury or damage to any person or property.

11. VARIATION OF WARRANTY AND EXCLUSION

Should our warranty and exclusion be unacceptable we are prepared to negotiate for variation in their terms but only on the basis of an increase in the price to allow for any additional liability or risk which may result from the variation.

Purchasers are advised to insure against any risk or liability which they may incur and which is not covered by our warranty.

12. RISK AND RETENTION OF TITLE

(a) goods supplied by us shall be at the Purchaser's risk immediately upon delivery to the Purchaser or into custody on the Purchaser's behalf or to the Purchaser's Order. The Purchaser shall effect adequate insurance of the goods against all risks to the full invoice value of the goods, such insurance to be effective from the time of delivery until property in the goods shall pass to the Purchaser as hereinafter provided.

(b) property in the goods supplied hereunder will pass to the Purchaser when full payment has been made by the Purchaser to us for :-

(i) the goods of the subject of this contract.

(ii) all other goods the subject of any other contract between the Purchaser and us which, at the time of payment of the full price of the goods sold under this contract, have been delivered to the Purchaser but not paid for in full.

(c) until property in the goods supplied hereunder passes to the Purchaser in accordance with paragraph (2) above.

(i) the Purchaser shall hold the goods in a fiduciary capacity for us and shall store the same separately from any other goods in the Purchaser's possession and in a manner which enables them to be identified as our goods.

(ii) the Purchaser shall immediately return the goods to us should our authorised representative so request. All the necessary incidents associated with a fiduciary relationship shall apply.

(d) the Purchaser's right to possess the goods shall cease forthwith upon the happening of any of the following events, namely :-

(i) if the Purchaser fails to make payment in full for the goods within the time stipulated in clause 4 hereof.

(ii) if the Purchaser, not being a company, commits any act of bankruptcy, makes a proposal to his or her creditors for a compromise or does anything which would entitle a petition for a Bankruptcy Order to be presented.

(iii) if the Purchaser, being a company, does anything or fails to do anything which would entitle an administrator or an administrative receiver or a receiver to take possession of any assets or which would entitle any person to present a petition for winding up or to apply for an administration order.

(e) the Purchaser hereby grants to us an irrevocable licence to enter at any time any vehicle or premises owned or occupied by the Purchaser or in the possession of the Purchaser for the purposes of repossessing and recovering any such goods the property in which has remained in us under paragraph (2) above. We shall not be responsible for and the Purchaser will indemnify us against liability in respect of damage caused to any vehicle or premises in such repossession and removal being damaged which it was not reasonably practicable to avoid.

(f) notwithstanding paragraph (3) hereof and subject to paragraph (7) hereof, the Purchaser shall be permitted to sell the goods to third parties in the normal course of business. In this respect the Purchaser shall act in the capacity of our commission agent and the proceeds of such sale :-

(i) shall be held in trust for us in a manner which enables such proceeds to be identified as such, and ;

(ii) shall not be mixed with other monies nor paid into an overdrawn bank account.

We, as principal, shall remunerate the Purchaser as commission agent a commission depending upon the surplus which the Purchaser can obtain over and above the sum stipulated in this contract of supply which will satisfy us.

(g) in the event that the Purchaser shall sell any of the goods pursuant to clause (6) hereof, the Purchaser shall forthwith inform us in writing of such sale and of the identity and address of the third party to whom the goods have been sold.

(h) if, before property in the goods passes to the Purchaser under paragraph (2) above the goods are or become affixed to any land or building owned by the Purchaser it is hereby agreed and declared that such affixation shall not have the effect of passing property in the goods to the Purchaser. Furthermore if, before property in the goods shall pass to the Purchaser under paragraph (2) hereof, the goods are or become affixed to any land or building (whether or not owned by the Purchaser), the Purchaser shall:-

(i) ensure that the goods are capable of being removed without material injury to such land or building.

(ii) take all necessary steps to prevent title to the goods from passing to the landlord of such land or building.

(iii) forthwith inform us in writing of such affixation and of the address of the land or building concerned.

The Purchaser warrants to repair and make good any damage caused by the affixation of the goods to or their removal from any land or building and to indemnify us against all loss damage or liability we may incur or sustain as a result of affixation or removal.

(i) in the event that, before property in the goods has passed to the Purchaser under paragraph (2) hereof, the goods or any of them are lost, stolen, damaged or destroyed :-

(i) the Purchaser shall forthwith inform us in writing of the fact and circumstances of such loss, theft, damage or destruction.

(ii) the Purchaser shall assign to us the benefit of any insurance claim in respect of the goods so lost, stolen, damaged or destroyed.

13. NON-PAYMENT

If the Purchaser shall fail to make full payment for the goods supplied hereunder within the time stipulated in clause 4 hereof or be in default of payment for any other reason then, without prejudice to any of our other rights hereunder, we shall be entitled to stop all deliveries of goods and materials to the Purchaser, including deliveries or further deliveries of goods under this contract. In addition we shall be entitled to terminate all outstanding orders.

14. RISK

All goods sold by us shall be at the sole risk of the Purchaser from the date of despatch by us of the invoice for their price.

15. VALUE ADDED TAX

All prices quoted are exclusive of Value Added Tax which will be charged at the rate ruling at the date of despatch of invoice.

16. TRADE SALES ONLY

We are only prepared to deal with those who are not consumers within the terms of the Unfair Contract Terms Act 1977, the Sale of Goods Act 1979 and the Supply of Goods and Services Act 1982. Accordingly any person who purchases from us shall be deemed to have represented that he is not a consumer by so purchasing.

17. JURISDICTION

The agreement is subject to English/Scottish law and any dispute arising hereunder shall be settled in accordance therewith dependent upon the location.

